


How to Build a CNC Machine

Rich Loen

- rich@loen.design
- www.loen.design
- [instagram.com/loen.design](https://www.instagram.com/loen.design)
- [youtube.com/richloen](https://www.youtube.com/richloen)

Chris Manning

- @silver_hand most everywhere
- Offhours.show









Building a CNC Machine

- Overview
- Hardware
- Electronics
- Control PC
- Control Software
- Design Software and process
- Resources
- Questions

Going to focus more on CNC Routers, but most info applies to CNC Mills and Lathes as well.

Safety

- NOT A JOKE. WE ARE TALKING ABOUT VERY DANGEROUS MACHINES.
- This is the first machine in your shop that will move on its own and try to kill you.
- You need to think about escape routes, Emergency Stop, Limit Switches, How you will call 911.
- Test cuts in the air with the spindle OFF.
- MAKE A CHECK LIST AND FOLLOW IT BEFORE YOU HIT GO.
- Wear ear and eye protection
- Don't leave it alone. You will be tempted to...

Why use a CNC?

- Very similar to the transition between using a typewriter and a computer.
- Accurate
- Repeatable
- Fast
- It can work while you do other things.
- You can try something, tweak it, and cut it again. Like reprinting a single page of a document.
- Always finding new uses
- Can work with larger bits
- Can work with extremely small bits
- Convenient when you have multiple items to make

But, it has its place.

Often still use a table saw, chop saw, planer, etc.

Furniture




Furniture



Furniture



Furniture



Furniture



Furniture



Furniture


SketchChair




Furniture




Art




Art



Art



PCBs



PCBs



Components of a Design



Components of a Design



Components of a Design



Components of a Design



Components of a Design



Components of a Design



Components of a Design



Components of a Design



Pens, Jewellery



Build vs Buy

- Lots of options. More coming every week.
- Small light machines: Shapeoko (carbide3d.com), X-Carve (inventables.com)
- Heavier Machines: CNCRouterParts.com, tormach.com, many others.
- EBay, banggood.com
- Auction web sites or in Montreal/Toronto. Often big machines for \$2500 - \$10,000. BUT, may need 3 phase power, etc. Can be complicated to program, calibrate, etc.
- Convert an existing machine


Hardware

- The key is rigidity, even for wood
- Machine structure - 8020 extrusions, wood, Maker Slide.
- Linear bearings
- Making things move

Wood Frame CNC Machine



8020 Frame



Linear Movement

- Linear Rails
- MakerSlide
- Angle Iron




Linear Movement

- Linear Rails
- MakerSlide
- Angle Iron



Linear Movement

- Linear Rails
- MakerSlide
- Angle Iron



Linear Movement

- Linear Rails
- MakerSlide
- Angle Iron



Making things move

- Acme threaded rods
- Ball screws
- Belts, pulleys
- Rack and Pinion
- What is backlash?



Making things move

- Acme threaded rods
- Ball screws
- Belts, pulleys
- Rack and Pinion
- What is backlash?




Making things move

- Acme threaded rods
- Ball screws
- Belts, pulleys
- Rack and Pinion
- What is backlash?



Making things move

- Acme threaded rods
- Ball screws
- Belts, pulleys
- Rack and Pinion
- What is backlash?



2D vs 2.5D vs 3D vs 5D

- 2D means there is no Z axis. Plasma Cutter. Water jet.
- 2.5D means there may be parts of the design at different depths, but once cutting, the machine stays at a given Z depth
- 3D means that the machine can cut while moving in X, Y and Z simultaneously. V-Carving
- 4th axis = a rotary axis.
- 5D means a rotary axis in two orientations.

V-Carving



V-Carving



Conversion kits

- G0704 or similar - tons of info on google - Hoss pages are good.
- Taig mill conversions are common - They sell kits.
- Nice because you start with a solid platform.



Electronics


- Motors
- Controllers
- Limit switches
- Power Supplies
- PC's

CNC Electronics



Spindle

5 or 6 Limit switches X+ X-, Slave-, Y+ Y-, Z+



E-Stop Switch



Invertor



220V

Spindle Speed




Relay Output



Spindle ON/Dir

Vacuum

Smooth Stepper



5-12V low current supply



110V




Computer Running Mach 3

3 or 4 Motor Drivers
3 or 4 Stepper Motors




30-60V 10-20A Supply



110V

Stepper motors

- Nema 17, Nema 23, Nema 34
- Ratings: Oz-Inch 100, 300, 500, 1000!
- Power supply - 24-48V 10-30A
- Stepper motor drivers
- Step and direction
- How to find winding pairs




Servo motor



- Overkill for most users
- Teknic SK Series is good
- Built-in driver
- Use with pulley and belt - reduction
- Use a beefy linear power supply




Control Hardware



- Smooth stepper - Connects to PC via USB or Ethernet
- G540 - The ole standby - but requires a 2-way parallel port
- Planet CNC or similar control computer
- Arduino-based controller. Some have built-in motor drivers, wifi, ethernet, usb, etc.

Control PC



- Parallel port vs USB vs Ethernet
- Get all s/w off the pc
- Use an older version of Windows - Windows 7
- Turn off auto-everything and every background task.


Manual control



- Xbox controller - find an old USB XBox controller.
- Special controller - pendant
- Keyboard
- Custom keyboard

Wires and connectors and Miscellaneous stuff

- For steppers, want braided, fairly heavy wires. 18 guage
- Limit switches - mechanical vs hall effect.
- E-Stop is essential.
- Relay outputs - 2 is good for controlling other equipment, spindle motors, lasers, etc. Easy to control from G-Code
- Power supply - Switching vs Analog
- Use latching connectors. Don't skimp




Spindle





- Simple: Use a small Dewalt Router or Bosch Colt. Mounts available.
- Air/water cooled spindle - many available on eBay. Think about collet size. Order spare collets. Don't skimp. ER11 collets ok for 1/4" bits. ER20 good for 1/2" bit. ER32 good for a mill.
- 3 Phase Inverter Hitachi vs others - lots of instructions on setting these up. Need to set about 5-10 parameters - but set as few as possible!
- Speed control via computer - Can be done through a digital or analog connection.

Control Software

- Mach3
- Mach4
- LinuxCNC
- PlanetCNC
- Arduino + GRBL
- Gcode



Flow of operations



Design Software

- Fusion 360
- Vectric V-Carve Pro
- Sketchup
- Rhino3D
- TinkerCAD.com
- OnShape.com
- librecad.com
- vectary.com
- OpenSCAD
- BobCAD

Good to know how to use more than one.

CAM

- Fusion 360
- Vectric
- BobCAD
- MakerCAM
- OpenSCAD
- RhinoCAM

CAM is often built into the CAD software these days.

Feeds and speeds software

- GWizard is pretty good.

The screenshot displays the GWizard: Machinist's Calculator software interface. The window title is "GWizard: Machinist's Calculator". The top navigation bar includes "Feeds/Speeds", "CAD/CAM", "ToDo", "Calculator", "Geometry", "GW Threads", "Quick Refs", and "Setup". The main interface is divided into several sections:

- Machine:** Generic CNC Router, Aluminum - Wrought (6061), Hardness: 20-150 BHN, Tool: Carbide Thread Mill, Crib: <No Crib>
- Tool:** Tool Diam. 0.5 in, Flutes 2, Stickout 1 in
- Mfg:** Optional Mfg's Data: Sfc Speed 880 sfm, Chipload 0.0026 ipt, Family: Generic
- Cut:** Cut Depth 0 in, Axial Engage.: 0%, Cut Width 0.5 in, Radial Engage.: 100%
- Results:** RPM 6388, Feedrate 33.113 ipm, IPR 0.0052, Normal/Simplify buttons
- Tips:** 3 Tips: Use Conventional Milling, Coolant, Mist, or Lubricant Recommended for Aluminum, Error: Min RPM too high for cut. Use a smaller cutter or one that can... A "Cheat Sheet" button and a "100%:Rough" indicator with a turtle and rabbit icon are also present.
- Limits:** HP Limit 2 hp (0%), Feed Limit 400 ipm (8%), RPM Limit 24000 (26%), Min RPM 12000, Surface Speed 836 sfm, Chipload 0.0026 ipt, Deflection 0 (0%), MRR (ci) 0, HP 0, Tool Torque 0
- Mini Calcs:** Mini-Calcs, Surface Finish, Helix, Vacuum, TSC, PCN
- Cut KB:** Search Cut KB, Add to Cut KB, Reset to Defaults

The status bar at the bottom shows "Inches", "Last Connect: 0 days / 0 fails", and "WizSize: 1028x873".



Work Holding

- Want low profile clamps
- Often good to make a jig
- Wood or Brass - less damage when the cutter hits it.
- Easy to screw into the spoil board
- There are plastic nails and special nailguns.
- Use tabs to keep work in place
- Vacuum Fixtures - MDF is porous!



CNC Lathes

- Conversion vs new build
- Spindle indexing for threading
- Differences in CAD and CAM
- Tool holding and changing

Machine Axis



Conversion vs Custom



How to make round things

- Lathe
- 4th Axis
- Stack slices
- Think outside the box



What goes wrong?

- Parts come loose. Fly across the room or jam up the cutter - break the bit.
- Forget to follow checklist. Forget to power on the inverter or similar.
- Wrong speed of cut
- Something comes loose. Locktite!
- Stepper misses steps. Can be mechanical issue or electrical (bad connector or noise)
- Don't stand in the path of cutters/parts that might fly

Online resources

- <https://loen.design>
- Vetric.com forums
- CNCCookbook.com
- YouTube
 - Frank Howarth: youtube.com/user/urbanTrash
 - This Old Tony: youtu.be/YBGqknN3gGs
 - NYCCNC
 - Lars Christensen
 - CNCNutz
 - Neo7CNC

Suppliers

- <https://loen.design/suppliers-list/>
- 8020 <http://ipecautomation.com/>
- CNCRouterParts.com
- Banggood.com
- Ebay
- <http://www.automation-overstock.com>

Thanks!

Rich Loen

- rich@loen.design
- www.loen.design
- [instagram.com/loen.design](https://www.instagram.com/loen.design)
- [youtube.com/richloen](https://www.youtube.com/richloen)

Chris Manning

- @silver_hand most everywhere.
- Offhours.show